


Sauter Lucki – Instruction Manual



Set the Comfort temperature: ☼

This is the desired temperature during the occupation of the room.

- a) Move the cursor to, the V2 indicator lights up.
- b) Set the dial to 5, the heating indicator V1 lights up if the room temperature is lower than desired.
- c) Wait a few hours for the temperature to stabilize.
- d) If the setting is suitable for you (possibly take a thermometer to check) locate the position once and for all. If the setting does not suit you, adjust the setting and return to c.

Set the Eco temperature: ☾

This reduces the temperature by a few degrees compared to the Comfort temperature. It is recommended to use this mode for periods of absence longer than 2 hours or at night.

Warning: since this lowers the Comfort temperature, it is important to first set this Comfort Temperature before adjusting the eco-lowering.

- a) Move the cursor to, the V3 indicator lights up.
- b) Set the knob to -3.5° , the V1 heater indicator lights up if the ambient temperature is lower than the desired Eco temperature.
- c) Wait a few hours for the temperature to stabilise.
- d) If the setting is suitable for you (take a thermometer if necessary to check) check the position once and for all. If the setting does not suit you, adjust the setting and return to point c.

Frost-free mode: ❄


This is the mode that keeps the temperature at about 7°C in the room during a prolonged absence from home (usually more than 24 hours).

Warning light V1:

This indicator indicates the periods during which the heater is heating. At stabilised temperature it flashes and if the temperature is too high it goes out.

Sleep mode of the device:

Position the cursor on 



Blocking of controls:

It is possible to block or limit the range of use of the knurled wheels and to lock the switch cursor to prevent inadvertent manipulation of the device (children,...).

- a) Remove the unit from its wall bracket.
- b) On the back of the thermostat box, detach the P counters from their brackets.
- c) Select position B to lock the knobs or position L to limit the range of use of the knobs.

Choose one of the M positions to lock the cursor in the desired mode.